

Deckchair Terms of Use & Care Instructions

- Use of the deckchair is entirely at your own risk. If you do not accept this risk, you must not use the deckchair.
- Children using or in the vicinity of the deckchair must be supervised by a responsible and sober guardian or adult at all times.
- The weight load on the deckchair must not exceed 250kg at any one time.
- You must not use the deckchair if you are intoxicated or under the influence of illicit drugs.
- Crockery, cutlery and glassware must not be used on or near the deckchair.
- Food and drinks must not be consumed whilst on or near the deckchair.
- Do not use the deckchair if it is windy or under any adverse weather conditions.
- Please do not climb, jump, stand or slide on the deckchair. It is intended to be used as a chair for sitting on so use it accordingly.
- When the deckchair is in use please ensure the lock is in place and it is on a firm/level surface.
- Exercise caution when folding or unfolding the deckchair so as not to catch your fingers or hands in the hinges of the deckchair.
- The deckchair requires at least two (2) able bodied persons to move in any circumstances.
- The deckchairs are suitable to be used outside but we recommend keeping them inside or undercover when not in use.
- The wood on the deckchair should be treated with a water based stain at least once each year.
- We recommend sanding any splinters on the deckchair as they occur.
- If you are regularly folding / collapsing the deckchair it may result in the bolts becoming loose. Please check and tighten the bolts on the deckchair regularly.
- If the deckchair is frequently used, we recommend replacing the sling regularly.
- We recommend hosing down the sling with fresh water and a soft brush on a regular basis to remove any surface dirt. For more stubborn stains, we recommend using warm water with a soft detergent and to rinse thoroughly. Do not use any pressure washer or any other cleaning product to clean the deckchair.
- We recommend reproofing the fabric on the sling after cleaning.
- To prevent mould, please ensure the chair is cleaned and completely dried naturally before storing the deckchair.